AMUR 3418100-3418101-3418102-3418105-3418106-3418107 Slide out the acrylic cover from the lamp body. Desolder the blue and brown wire, slide the LED mould out from the lamp body and in then install a new LED mould. Resolder the blue and brown wires and fix the mould on the body. Remove the plastic endcaps on the side (05)Loosen the wires on both sides (blue and brown wires) using a tool. Then change the driver and re-connect the wires on both sides. A. To replace the Driver follow steps 01, 02, 03, 04 Remove the plastic wall bracket Loosen the 2 side screws using a tool (01)B. To replace the LED mould follow steps 05, 06, 07