


1

Remove the cover




TOOL

Screwdriver

2

Loosen the screws on the diffuser




TOOL

Screwdriver

3

Take out the blue and brown wires from the terminal block

Take out the LED module




TOOL

Screwdriver

4

Connect the blue and brown wires from the terminal block

Install the new LED module




TOOL

Screwdriver

5

Reinstall the diffuser




TOOL

Screwdriver

6

Re-attach the lamp cover
Click it into place



TOOL