


1


Remove the cover



TOOL Screwdriver

2

Loosen the screws on the diffuser




TOOL Screwdriver

3

Take out the blue and brown wires from the terminal block

Take out the LED module




TOOL Screwdriver

4

Connect the blue and brown wires from the terminal block


Install the new LED module



TOOL Screwdriver

5


Reinstall the diffuser



TOOL Screwdriver

6

Re-attach the lamp cover
Click it into place



TOOL