



① Open the lamp cover



TOOL


② Loosen the screws on the diffuser to open it



TOOL

Screwdriver


③ Take out the LED board



TOOL

Screwdriver


④ Change the LED board



TOOL

Screwdriver


⑤ Re-attach the LED board
Fix the diffuser with screws



TOOL

Screwdriver

⑥ Re-attach the lamp cover



TOOL