



① Loosen the screws on the PC cover and open it.



Open the lamp cover

TOOL Screwdriver


② Take out the LED module from the cover



Loosen the screws on the LED board


TOOL Screwdriver

③ Take out the red and black wire of the driver from the LED module




TOOL Electric soldering iron

④ Re-solder the red and black wire of the new driver on the LED module




TOOL Electric soldering iron

⑤ Fix the LED board with screws to the lens module. Re-attach the new LED module and driver.



TOOL Screwdriver

⑥ Fix the PC cover with screws and re-attach the lamp cover.



TOOL Screwdriver