



① Open the cover




TOOL Screwdriver

② Loosen the fastening screw on the PC diffuser
Loosen the fastening screw on the LED board




TOOL Screwdriver

③ Take out the LED board




TOOL Screwdriver

④ install a new LED board




TOOL Screwdriver

⑤ Fix the LED board and PC diffuser with screws



TOOL Screwdriver

⑥ Fix the PC cover with screws



TOOL Screwdriver