


1


Open the lamp cover



TOOL Screwdriver

2


Loosen the screws on the inner and outer PC cover



TOOL Screwdriver

3

Loosen the screws on the LED module




Take out the blue and brown wire from the terminal block

TOOL Screwdriver

4

Fix the new LED module with screws




Connect the blue and brown wire to the terminal block

TOOL Screwdriver

5


Fix the inner and outer PC cover with screws



TOOL Screwdriver

6

Re-attach the lamp cover by clicking it into place



TOOL Screwdriver