





INFINITUS MOUNTED ON THE CEILING



INFINITUS AS A PENDANT (requires extra components TR0208 + TR0209)




INFINITUS INTERNAL TRACK POWER CONNECTION




*TR0118 (feeder) is only included with INFINITUS profiles that include accessories!

Connect the power cable inside the feeder:



MORE INFORMATION ONLINE

INFINITUS INSTALLATION HELP VIDEOS



INFINITUS PARTS OVERVIEW

