



① Loosen the screws on the PC cover and open it



Loosen the screws on the lamp cover and open it

TOOL Screwdriver


② Take out the LED module from the PC cover



Loosen the screws on the driver and driver holder


TOOL Screwdriver

③ Take out the red and black wire of the driver from the LED module




TOOL Electric soldering iron

④ Re-weld the red and black wire of the driver on the new LED module




TOOL Electric soldering iron

⑤ Attach the new LED module
Fix the driver and driver holder to the PC cover



TOOL Screwdriver

⑥ Fix the lamp cover with screws
Fix the PC cover with screws



TOOL Screwdriver