



① Loosen the screws on the PC cover and open it



Loosen the screws on the lamp cover and open it

TOOL Screwdriver


② Take out the LED module from the PC cover



Loosen the screws on the driver and driver holder

TOOL Screwdriver


③ Take out the red and black wire of the driver from the LED module



Take out the blue and brown wire from the terminal block

TOOL Screwdriver
Electric soldering iron


④ Re-solder the red and black wire of the new driver to the LED module



Re-connect the blue and brown wire from the terminal block


TOOL Screwdriver
Electric soldering iron

⑤ Attach the LED module
Fix the driver and driver holder to the PC cover



TOOL Screwdriver

⑥ Fix the lamp cover with screws
Fix the PC cover with screws



TOOL Screwdriver