



- A. Replace the driver by following steps 01, 02, 03, 04
- B. Replace the LED mould by following steps 05, 06, 07

