



A**TOOL**


screw driver

B**TOOL**


screw driver

C

Replace with a new driver,
connect the male and female connectors
connect the driver L&N to the terminal block

**TOOL**

screw driver

D**TOOL**

screw driver